

SAFETY INSTRUCTIONS

This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure that they do not play with the appliance.

• Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.

• If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

• This appliance is intended to be used in household only. It is not intended to be used in the following applications, and the guarantee will not apply for:

- staff kitchen areas in shops, offices and other working environments;

- farm houses;

- by clients in hotels, motels and other residential type environments;

- bed-and-breakfast type environments.

• Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

• Children shall not play with the appliance.

• This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are aged from 8 years and above and supervised. Keep the appliance and its cord out of reach of children aged less than 8 years.

• Clean all of the accessories that have been in contact with food, in hot soapy water immediately after use.

• Switch off the appliance and disconnect from supply before changing accessories or approaching parts that move in use.

PLEASE RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Please read these instructions carefully before first use. The appliance is designed for domestic use only. The manufacturer does not accept any liability and reserves the right to cancel the guarantees in the event of commercial or inappropriate use or failure to follow the instructions.

• For safety, this appliance is compliant with applicable standards and regulations:

- Regulations governing materials in contact with food.

- Check that the regulations concerning the rating plate of the appliance matches that of your electrical system. Any deviation from the rating plate of the appliance to that of the electrical system may result in damage to the appliance.

• Do not use this appliance on or close to open flames (gas cooker).

• Given the diverse standards in effect, if the appliance is used in a country other than that in which it is purchased, check it by calling the Approved Service Centre.

• Do not immerse the power cord in water or allow liquid to drip onto it.

• Do not allow long power, flexes, etc. to hang over the appliance or attachments when in use.

• Wait for all moving parts to stop before opening the appliance.

• Use the appliance on a solid, stable worktop, away from water splashes. Do not turn it over.

• Any intervention other than normal cleaning and maintenance by the customer must be carried out by an approved service centre.

• Never unplug the appliance by pulling on the cord.

• Do not use an extension lead if you are not fully familiar with its use or if it is not in good condition.

• Do not use your appliance if it does not operate as it has been designed to do or if the power cord or plug is damaged. To maintain safety, these parts must be replaced by an Approved Service Centre.

• This product has been designed for domestic use only. The manufacturer accepts no responsibility, and the guarantee does not apply, for damage caused by commercial, inappropriate use or failure to comply with the instructions. Always unplug the appliance when not in use.

• Do not exceed the maximum quantities of operating ingredients.

• Do not exceed the maximum quantities of oil and/or butter.

• Redring Österrike tekniskel kontakten om att du har tekniskt kunnande.

• Koristis originales rastnike komponente.

• Koristis originales rastnike komponente.</p

