


Tefal®

Telesne vage



UPUTSTVO ZA UPOTREBU

Pažnja




🕒 10"




Baterija

Upotreba




AUTOMATSKO UKLJUČIVANJE



MIN 10 kg –
2 st – 22 lb

MAX 160 ili 150 kg –
23 ili 25 st – 330 ili 350 lb

Posebne poruke




Lithium 3V CR2032

PROMENITE BATERIJU



kg – st – lb





Aparat sadrži jednu ili više baterija. Pomozite očuvanju okoline tako što ćete potrošene baterije odložiti u za njih predviđeno mesto.